TIRED SLEEPERS?

SPIKE FAST

The 25 minute solution that can add ***at least 5 years**** to your timber life!

**Based on 14 years data following the introduction of the product on high MGTPA infrastructure*

STEP 1 — **0mins**

Remove loose screws and fill holes with SPIKE FAST

STEP 2 — **20mins**

Drill as new timber

STEP 3 — **25mins**

Replace screws and open to traffic

DWG INFRACO

For product information, samples and demonstrations, contact:

T: +44(0)1664 650666 E: fast@dwguk.com www.dwguk.com

Network Rail · INFRABEL Right On Track · London Underground

Approvals: Network Rail PA05/05187 - London Underground APR228